
Trim to fit with your router equipped with a ½" straight bit.
GUIDE
Trim to fit with your portable circular saw.
¾"
18"
¾"
1½"
BASE
½"
1½"
CLEAT
Distance from the edge of your router base to the edge of a ½" straight bit plus ⅛"
Distance from the motor edge of your circular-saw base to the inside edge of the blade plus ⅛"